

Mini MP4 Media Player

User Guide



Here's what else you can do with the Mini MP4 Media Player controls:

To	Do This
Turn ON/OFF the MP4 Player	Slide the power switch from OFF to ON and vice versa to power off
Set the correct timezone	Use the Right (▶) and Left (◀) buttons to navigate the main menu. Using the Play/Pause (▶) button to enter; select Toolbox → System Setting → Desktop Set → TimeZone Set → GMT+00/GMT+01
Set the date and time	Again using the Right (▶) and Left (◀) buttons to navigate the main menu, using the Play/Pause (▶) button to enter; Toolbox → World Clock → GMT, London . Once in the set-up screen use the Right (▶) and Left (◀) buttons to set the correct Day, Month, Year, Hour and Minute using the (V) Volume button to select the correct column and the Play/Pause (▶) button as an enter once correct
Choose a menu item	Use the Forward (▶) and Backward (◀) buttons to move up and down the Menu options and press enter using the Play/Pause (▶) button
Go back to a previous menu	Press the Back (◀) button
Browse for a song	From the main menu using the Left (◀) and Right (▶) buttons to navigate the device selecting Music using the Enter (▶) button to select, then using the Up (◀) and Down (▶) buttons to navigate the relevant menus i.e. All Music, Artist, Album, Genre etc. to your selected track, pressing the Play/Pause (▶) button again to start playing your choice
Browse for video	From the main menu select Video and then SD using the Select (▶) button. You should now have a list of all the compatible videos you have copied onto the Micro SD. Using the Up (◀) and Down (▶) buttons to navigate to your choice pressing the Play/Pause (▶) button to start viewing
Play/Pause a song or video	Select a song or video using the Left/Up (◀) and Right/Down (▶) buttons to navigate the device pressing the Play/Pause (▶) button to pause or play
Change the volume	Looking at the volume icon at the bottom on the right-hand side; press the Volume (V) button - notice the volume icon turns white, Press the (▶) button to increase the volume and the (◀) button to decrease the volume. Once finished selecting the volume press the Volume (V) button again to resume the players controls – the volume icon should now have turned from white back to turquoise
Enable the repeat function	Looking at the A-B icon at the bottom on the left-hand side of the screen; press and hold the Vol + button to set the A -point where you want to start the repeat function and again press and hold the Vol + button to set the B -point at the place where you want to end the repeat function
Skip to the next song, video or next page in an eBook	Press the Next (▶) button to skip to the next song/page or the Previous (◀) button to skip to the previous song or page of eBook
Fast-forward or rewind a song	Press and hold Next/Fast-forward (▶) or press and hold Previous/Rewind (◀)
To view all of your files on the Micro SD / TF Card within a single folder	Using the main menu select File Manager → SD function and press the Enter (▶) button
Change any playback, display, desktop, EQ settings or repeat functions whilst playing a song/video	Press the Menu (M) button and using the Next (▶) or Previous (◀) buttons to move up and down the menu. To select settings press the Enter (▶) button.

Adding Media Files to your Micro SD

Simply copy your videos, pictures, music and E-books to the ROOT of the micro SD taking into account the files which are supported and the files that aren't. A compatible file format list can be found below:

- **Audio formats:** MP3 / WMA / WMV / APE / FLAC

- **Video formats:** MPEG-4 / MP4 / ASF / 3GP / FLV (320x240)

- **Picture formats:** JPEG / BMP / GIF

- **E-Book formats:** TXT

NOTE: If you are experiencing poor quality video, out of sync audio or just unable to play a certain formats try converting videos to MPEG-4, 320x240 (resolution) at 29.9 frames per second for best results.

Transferring your media files using Mini USB:

1. Insert your micro SD / TF Card into the device
2. Connect the MP4 media player to your computer using the included mini USB cable and wait for the USB icon to appear on the players screen
3. The device should now automatically open as a folder; you may need to open the drive through **My Computer**. Copy ALL of your media files to the ROOT of the micro SD and wait for the transfer to complete. Do NOT copy files into separate folders this will cause the player to malfunction when updating the file information.
4. Eject the device in My Computer or by clicking the **Safely Remove Hardware** icon in the Windows system tray and selecting the specific device
5. Pull out the mini USB connector and your device is now ready to be used.

Transferring your files directly to Micro SD:

1. Insert your micro SD / TF Card and using a compatible card reader copy all of your media files to the ROOT of the Micro SD and wait for the transfer to complete. Do NOT copy files into separate folders as this will cause the player to malfunction when updating the file information.
3. Insert your media filled micro SD card into the MP4 media player
4. Turn on the player and wait for the start-up screen; your device is now ready to be used.

Connecting the Mini MP4 Media Player

You can connect the MP4 Player to your computer to charge the device but in order to add your music, videos, photos, eBooks and other files to your micro SD, simply take out the Micro SD and use a reader to transfer your required files and then reinsert the micro SD into the device.

NOTE: The USB port on most keyboards and monitors do not provide enough power to charge the MP4 Media Player. Instead either use a USB 2.0 port on your computer or use a USB mains adaptor (*sold separately.*)

Disconnecting the Mini MP4 Media Player

It's important if connecting the device to a computer not to disconnect this device while it's charging. You can see if it's OK to disconnect by looking at the players screen. Don't disconnect the device if you see the player is still in charge mode as this could damage important files on your device.

If you're using a Windows PC, you can also eject the device in My Computer or by clicking the Safely Remove Hardware icon in the Windows system tray and selecting the specific device.

If you're using a Mac, you can also eject the Mini player by dragging the icon on the desktop to the Trash.

About the Players Battery

The Mini MP4 Media Player has an internal, non-user-replacement battery. For best results, the first time you use the player, let it charge for about four hours or until the battery icon in the status area of the display shows that the battery is fully charged. If the device isn't use for a while, the battery may need to be charged to bring the device back to life.

NOTE: As with most battery powered devices, some battery power is consumed whilst the device is switched off.

The MP4 Player is fully charged in about three hours. If you charge the player while playing music, watching videos, listening to the radio or even viewing an eBook, this may take longer.

Charging the Mini MP4 Players Battery

Connect the MP4 Player to a USB 2.0 port on your computer. The computer must be turned on and not in sleep mode. If the battery icon on the players screen shows the Charging screen, the battery is charging. If it shows the Charged screen, the battery is fully charged. If you don't see the Charging screen, the Mini MP4 Media Player might not be connected to a high-power USB port. Try another USB port on your computer or use a USB mains adaptor (*sold separately.*)



iWisoft Free Video Converter

a powerful, high-quality freeware video converter.

It can easily convert video/audio between all popular formats. It can convert video/audio from one format to another, rip audio from video, convert video to image series, animated gif.

The free video converter provides you optimised output profiles, you can easily convert video/audio for not only the Mini MP4 Media Player but also iPod, iPhone, PSP, Zune and many other digital devices.

You can adjust codec, bit rate, frame rate, video size, audio channel, sample rate, audio volume etc. for an output format.

And the video converter provides many useful video editing functions, like cropping, trimming, merging, adding watermark, subtitle etc.

Key Features

- Convert general video

Convert various videos to AVI, MPEG, WMV, DivX, XviD, MP4, H.264/AVC, FLV, MKV, RM, 3GP, 3G2, MOV, etc., and extract audio to AAC, AC3, MP3, MP2, OGG, RA, WAV, WMA, M4A from videos.

- Support HD Video conversion

Convert video between multiform High-Definition movies, such as H.264/MPEG-4 AVC, AVCHD Video (*.m2ts, *.mts), Apple TV h.264 720P, MKV, HD WMV, MPEG2/MPEG-4 TS HD Video, etc., as well as convert video from High-Definition to Standard-Definition for watching.

- Convert between any audio formats

Convert between MP3, MP2, WMA, WAV, OGG, M4A, AC3, AAC, RA, APE, FLAC, AIFF, MPA audio and more.

- Support all popular digital devices

Directly convert video for playback on iPod, iPhone, Apple TV, PSP, PS3, Xbox 360, Wii, Pocket PC, Blackberry, Mobile phones, Zune, Creative Zen, Archos, HP iPAQ, iRiver and more digital devices.

- Support batch conversion

Support converting multiple video & audio files in batches to save your time! Not only that, it can handle one file to multiple formats at the same time.

- Provide optimised video & audio profiles

Luxuriant, optimized and classified video & audio profiles help you easily convert any video and audio to fit your digital devices.

- User defined video profiles

Allow you to adjust any profiles by setting video codec, video size, video bit rate, audio codec, audio bit rate, audio channel, audio volume, etc. to convert, and you can save your settings as user defined profiles for future use.

- Estimate output file size

A smart bit rate calculator tool is built-in in this video converter to estimate the output file size.

- Crop video

Easily crop frame size to keep your wanted area in the frame.

- Trim Video & Audio

Trim your video or audio to convert your favourite movie or music clips.

- Special video effect

Add special effect on output video, such as adjusting gamma, brightness, contrast, saturation, and gray, emboss, negative, old film effects.

- Add watermark


Add text or graphic logo with customized transparency, size and position onto your created video.

- Preview video effect


Preview the video in real-time while editing effect before conversion.

Installing and Using iWisoft Freeware Video Converter

1. Click [here](#) to download the **iWisoft Freeware Video Converter** and install the program
2. After installing the software, launch the program and click  to load video files
3. Select the output profile as shown below for **best** results using this device. The "**Recent**" option will record your recent using automatically and it is convenient to be used afterward.



4. Next you need to change the  and select the values shown below for best results.
[Codec: divx] [Size: 320x240] [Rate: 29.97 fps] [Bitrate $\pm$: 768 kbps] [Ratio:16:9]



5. Select the output folder in the bottom left-hand corner and select the folder where you would like to save your newly converted videos.

NOTE: I have chosen the E: folder as I do not wish to have separate copies of each video so have elected to save the videos directly to the micro SD but of course you can save these anywhere.



6. To change the output aspect ratio click  and a new editing window should appear. Move your mouse cursor onto one of the eight small adjustment boxes on the cropping frame (the dashed line) and drag the crop frame to crop the video. The cropped result will be shown on the Output Preview on the right-hand side. This process only takes a few seconds for each video and no other settings have to be changed once your happy with your selection click **OK**. These settings will give you the optimum video quality Vs. screen resolution without viewing videos in the letterbox effect giving all-round better viewing for this particular MP4 player.



7. Finally you need to convert the video to your selected output folder pressing the **Start** button and your video will start to convert giving you a report of its progress. Add these files to the **ROOT** of the Micro SD / T-Flash memory card - if you haven't already?

Safety and Cleaning

Read all safety information below and operating instructions before using the Media Player to avoid injury.

WARNING: Failure to follow these instructions could result in fire, electric shock, or other injury or damage.

Important Safety Information

Handling the Media Player

Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects into the device.

Avoiding water and wet locations

Do not use this device in the rain, or near washbasins or other wet locations. Take care not to spill food or liquid onto the device. In case the device gets wet, unplug all cables, turn the device off, and slide the Power switch to off before cleaning, and allow it to dry thoroughly before turning it on again. Do not attempt to dry the Mini MP4 Player with an external heat source such as a microwave oven or hair dryer. If your device has been damaged as a result of exposure to liquids this is not covered by the warranty nor makes the device serviceable.

Repairing the Mini MP4 Media Player

Never attempt to repair this player yourself as this device does not contain any user-serviceable parts. If the MP4 Player has been submerged in water, punctured, or subjected to a severe fall, do not use it.

Avoiding hearing damage

Permanent hearing loss may occur if the earbuds or headphones are used at high volume. You can adapt over time to a higher volume of sound that may sound normal but can be seriously damaging your hearing. If you experience ringing in your ears or muffled speech, stop listening and have your hearing checked. The louder the volume, the less time is required before your hearing could be affected. Hearing experts suggest that to protect your hearing limit the amount of time you use earbuds or headphones at high volume. Avoid turning up the volume to block out noisy surroundings and turn the volume down if you can't hear people speaking near you.

Driving and riding safely

Use of this Media player alone, or with headphones (even if used in only one ear) while operating a vehicle is not recommended and is illegal in some areas. Check and obey the laws and regulations on the use of mobile devices in areas where you drive or ride. Be careful and attentive while driving or riding a bicycle. Stop using the device if you find it disruptive or distracting while operating any type of vehicle, or performing any other activity that requires your full attention.

Important Handling Information

NOTICE: Failure to follow these handling instructions could result in damage to your Media Player or other property.

Carrying the Mini MP4 Player

This electrical device contains sensitive components, including, in some cases, a hard drive. Do not bend, drop, or crush the device itself. If you are concerned about scratching your device, you can use one of the many cases sold separately.

Using connectors and ports

Never force a connector into a port. Check for obstructions on the port. If the connector and port don't join with reasonable ease, they probably don't match. Make sure that the connector matches the port and that you have positioned the connector correctly in relation to the port.

Operating your device in acceptable temperatures

Operate your device in a place where the temperature is always between 0° and 35° C (32° to 95° F). In low-temperature conditions, this device play time may temporarily shorten and battery charge time may temporarily lengthen. Store your device in a place where the temperature is always between -20° and 45° C (-4° to 113° F). Don't leave this player in your car, because temperatures in parked cars can well exceed this range. When you're using your player or charging the battery, it is normal for the device to get warm. The exterior of this device functions as a cooling surface that transfers heat from inside the unit to the cooler air outside.

Keeping the outside of device clean

To clean this device, unplug all cables, turn the device off, and slide the Power switch to **OFF**. Then use a soft, slightly damp, lintfree cloth. Avoid getting moisture in openings. Don't use window cleaners, household cleaners, aerosol sprays, solvents, alcohol, ammonia, or abrasives to clean any electrical device.